GE
Lighting Solutions

Installation Instructions

Adaptors for DR2 LED Traffic Signal Lamps

BEFORE YOU BEGIN

Read these instructions completely and carefully.

Prepare Electrical Wiring

Electrical Requirements

- Do not use in wet locations
- Follow all National Electric Codes (NEC) and local codes.

WARNING / AVERTISSEMENT

Risk of Electric Shock. Disconnect Before Servicing or installing product.
Risque de choc électrique. Couper l'alimentation avant le dépannage ou avant l'installation du produit.

Installation Steps:

NOTE: To avoid scratches to the optical surface, **DO NOT** place lamp on the front surface.

Step 1: Install o-ring in the groove between external lens and black housing. **CAUTION** **Risk of Damage** Failure to place o-ring will not seal the adaptor/lamp interface.	
Step 2: Pass wires through adaptor ring.	
Step 3: Align the arrow on the adapter as shown in the image.	

Installation Instructions (cont'd)

Adaptors for DR2 LED Traffic Signal Lamps

Step 4: Press the adapter up to the front shell: Surface of adapter should be in line with the shell.	
Step 5: Rotate adapter clockwise to align both arrows until locked. **⚠ CAUTION** **Risk of Damage** A clipping sound should be heard when adaptor ring locks with lamp. Failure to do so may cause lamp to disengage during operation.	

GE Lighting Solutions, LLC is a subsidiary of the General Electric Company. The GE brand and logo are trademarks of the General Electric Company.
© 2010 GE Lighting Solutions, LLC. Information provided is subject to change without notice. All values are design or typical values when measured under laboratory conditions.